




Contents

- 1. Instructions for Writing FWR-supported Characters
(Russian, English, Numbers, and Special Characters)
- 2. Considerations When Using FWR
- 3. Tips for Using FWR Settings
- 4. Tips for Using FWR Text Input
- 5. Tips for Using FWR Game
- 6. Tips for Using FWR Navigation & Scroll
- 7. Tips for Using FWR Finger Dial



It's different



PG-2800

Quick Reference Guide


PANTECH

6.Tips for Using FWR Navigation & Scroll

FWR Navigation & Scroll Function

When the FWR function is on, you can use it as Navigation Scroll and Double Click keys 4 ways or 8 ways.

Double click an item that you want to select.



To move from 5. Multimedia to 6. Settings, turn the FWR function on and then draw a line from the left to the right.




To move from 1. Messages to 2. Contacts, turn the FWR function on and then draw a line from the left to the right.



To scroll, turn the FWR function on and then draw a line from the top to the bottom.


7.Tips for Using FWR Finger Dial

Finger Dial Function



Press the left side longer then enter numbers (FWR On Default).

■ You can set from 1 to 9.



1.Instructions for Writing FWR-supported Characters

Russian

Russian Capital Letters

A	А	А	А²	C	С	С
Б	Б	Б		Т	Т	Т
В	В	В		У	У	У
Г	Г	Г		Ф	Ф	Ф
Д	Д	Д		Х	Х	Х
Е	Е	Е		Ц	Ц	Ц
Ж	Ж	Ж		Ч	Ч	Ч
З	З	З		Ш	Ш	Ш
И	И	И		Щ	Щ	Щ
Й	Й	Й		Ъ	Ъ	Ъ
К	К	К		Ы	Ы	Ы
Л	Л	Л		Ь	Ь	Ь
М	М	М		Э	Э	Э
Н	Н	Н		Ю	Ю	Ю
О	О	О		Я	Я	Я
П	П	П		Ё	Ё	Ё
Р	Р	Р				

Russian Small Letters

a	а	а		c	с	с
б	б	б		т	т	т
в	в	в		у	у	у
г	г	г		ф	ф	ф
д	д	д		х	х	х
е	е	е		ц	ц	ц
ж	ж	ж		ч	ч	ч
з	з	з		ш	ш	ш
и	и	и		щ	щ	щ
й	й	й		ъ	ъ	ъ
к	к	к		ы	ы	ы
л	л	л		ь	ь	ь
м	м	м		э	э	э
н	н	н		ю	ю	ю
о	о	о		я	я	я
п	п	п		ё	ё	ё
р	р	р				

English

English Capital Letters

A	А	А²	N	Н	Н²	Н
B	Б	Б	O	О	О	О
C	С		P	П	П²	
D	Д	Д	Q	Қ	Қ²	Қ
E	Е	Е²	R	Р	Р²	
F	Ф	Ф²	S	С		
G	Г	Г²	T	Т		
H	Н	Н²	U	У	У	
I	И	И²	V	В		
J	Й	Й	W	Ш	Ш²	
K	К	К²	X	Х	Х²	
L	Л		Y	У²	У²²	
M	М	М	Z	З	З²	

English Small Letters

a	а	а²	n	н	н²	
b	б	б	o	о	о	о
c	с		p	п	п²	
d	д	д²	q	қ	қ²	қ
e	е		r	р		
f	ф	ф²	s	с		
g	г	г²	t	т	т²	т
h	н	н²	u	у		
i	и	и²	v	в		
j	й	й²	w	ш	ш²	
k	к	к²	x	х	х²	х
l	л		y	у²	у²²	
m	м	м	z	з	з²	

Numbers & Special Characters

.	·	!	!²	@	@²
.	·	-	-²	:	:²
?	²	*	²		

0	О	О²	4	У²	8	Ш²	Ш²²
1	/	¹	5	У²²	9	У²²²	
2	²	²²	6	Г			
3	³	³²	7	У²²²	У²²²²		

[.] Write on the bottom half of the sensor [²] Write on the top half of the sensor

2.Considerations When Using FWR

Considerations When Using Finger Writing Recognition Sensor

- To turn on/off FWR sensor, press the right side Camera key longer in Text Input mode.
- To use Finger Dial, press the left side Up key longer in Idle mode.
- FWR functions only in FWR Active Area (keypads with numeric keys).
- For correct functioning, you must enter FWR-supported characters including English (capital and small letters), Russian, numbers, and special characters according to the writing instructions in the Manual.
- Use your finger. It may not function well if you use stylus pen or ballpoint pen, wear gloves, or use more than two fingers at once.
- Long fingernails may damage the sensor. It is better to enter with the fingertip rather than using fingernails.
- If you use the FWR function for a long time, you may have a stiff finger or shoulder. Avoid using this function while you are on the move because it can cause accidents.
- It may not function well if you write with wet hands or the FWR sensor is wet.
- FWR is turned off while transmitting a file via Bluetooth.



3.Tips for Using FWR Settings

Tips for Using Finger Writing Settings

- To change FWR default setting, press 6.Settings → 4.Finger Writing Settings → 1.FWR Default(FWR default is On).
- To practice this function, press 6.Settings → 4.Finger Writing Settings → 2.FWR Training.
- If you press the Help Soft key on the bottom left side of the screen during FWR Training, instructions with illustrations will appear.
- In FWR Training, you can select among Russian capital and small letters, English capital and small letters, numbers, and special characters.



4.Tips for Using FWR Text Input



Note

- To turn the FWR function on/off, press the right Camera/FW key longer in Text Input mode.
- Only enter one character at a time because FWR cannot recognize more than two characters at the same time.
- If you draw a line from the right to the left, it works as backspace and you can delete the preceding character.
- If you draw a line from the bottom left to the top right, you can insert a space character.

Key Definition

Action	Note
[*] Short press	Word Search (T9 Mode)
[*] Long press	ABC → Symbol
Camera Hotkey	Finger Writing On/Off (Long press)
[#] Short press	Abc → ABC → abc (ABC Mode)
[#] Long press	T9 → Multi tap → 123 → Symbol

Character Recognition by Input Types


Type	Action
↑ ABC	Recognizes all characters as capital letters.
↑ Abc	Recognizes only the first character as capital letters.
abc (with no marks)	Recognizes all characters as small letters.
123	Recognizes only numbers. Supported only in text input field. Not supported in number-only field.
Symbol	Not supported FWR. Only key input is possible.

Character Recognition by Languages

Language	Action	Remarks
English	Recognizes English, special characters (. , - ? ! ' @ :).	Recognizes special characters entered with No. 1 key only.
Russian	Recognizes Russian, special characters (. , - ? ! ' @ :).	


4.Tips for Using FWR Text Input

Messages




SMS:

- 1.Messages
- 1.Write New
- 1.Text Msg.
- Write (FWR On Default)



MMS:

- 1.Messages
- 1.Write New
- 2.Multimedia Msg.
- Write (FWR On Default)



E-mail:


- 1.Messages
- 1.Write New
- 3.E-mail
- Write (FWR On Default)

Contacts



Search:


2. Contacts
- 1.Search
- 1.Name Search
- Input (FWR On Default)



Add Contact:


2. Contacts
- 2.Add Contact
- Save to
- Input (FWR On Default)

Memo & Electronic Dictionary




Memo:

7. Organizer
- 3.Memo
- 1.Text Memo
- Write (FWR On Default)



E-Dictionary:

- 7.Organizer
10. Electronic Dictionary
1. English-Russian
- Input (FWR On Default)



E-Dictionary:

- 7.Organizer
10. Electronic Dictionary
2. Russian-English
- Input (FWR On Default)


5.Tips for Using FWR Game

FWR Game (Crab Shooter)

You can select between Navigation Key and FWR Sensor to play the game.



- Games : → 5.Multimedia → 3. Games
→ 1. Crab Shooter
→ FWR Navigation On Default



- Turn left: (←)
Turn right: (→)
Shoot: (⏏)
- Turn left: Draw a line from the right to the left.
Turn right: Draw a line from the left to the right.
Shoot: Double click in the FWR Sensor Area.

